



Mark means lamp contains mercury.
Follow disposal laws. See www.lamprecycle.org

*Le marquage indique que la lampe contient du mercure.
Respecter les lois concernant l'élimination des déchets.
Veuillez consulter le site www.lamprecycle.org*

Ballast Replacement

- NOTE: The ballast is replaceable with the use of a qualified electrician without the cutting of wires.
- Turn Power off.
- Remove Diffuser.
- Replace ballast with the same model.

Replace Ballast Depending On Ballast Type Below

A. Twist Lock Ballast

1. Pull lamp straight out.
2. Twist ballast assembly and remove from base.
3. Install new ballast by twistlocking into place.

B. Square Cased Ballasts

1. (If applicable, disconnect the quick connect on the primary side of the ballast.) Carefully undo input wire connections between the supply and the ballast.
2. If applicable, use a screw driver to bend tabs on socket cover.
3. Disconnect the secondary ballast wires to the socket by inserting a small screwdriver into the rear of the socket to release the wire lead, or disconnecting the wire nuts.
4. Remove ballast mounting screws and remove ballast from fixture assembly.
5. Replace ballast with the same model, secure ballast to fixture assembly, insert secondary ballast wires by pushing them into the rear of the socket, or with wire nuts, and make proper wiring connections to the supply wire.
6. Resecure socket assembly with tabs (if applicable).

C. Circline Ballasts

1. Separate the 120v connection between the ballast and the house supply wire.
2. Disconnect the secondary ballast wires to the lamp by disconnecting the plug.
3. Remove ballast mounting screws and remove ballast from fixture assembly.
4. Replace ballast with the same make and model, secure ballast to fixture assembly, make proper wiring connections to the supply wire and install the socket plug to the lamps.

D. Self-Ballasted Lamp

1. Twist self ballast lamp assembly (from ballast) and remove from base. Be sure not to remove by twisting from spiral glass lamp.
2. Install new ballast by twist-locking into place.

Remplacement du Ballast

- REMARQUE : Il est possible, pour un électricien qualifié, de remplacer le ballast sans couper les fils.
- Couper le Courant.
- Retirer le diffuseur.
- Remplacer le ballast par un modèle identique.

Remplacement du Ballast en Fonction du Type Ci-dessous

A. Ballast Emboîtement à Baïonnette

1. Retirer la lampe en tirant.
2. Tourner le ballast et retirer de la base.
3. Monter le ballast neuf en en tournant pour verrouiller en place.

B. Ballasts Boîtier Carré

1. (Le cas échéant, déconnecter le raccord rapide du primaire du ballast.) Défaire soigneusement les connexions entre l'alimentation et le ballast.
2. Le cas échéant, utiliser un tournevis pour plier les languettes du couvercle du ballast.
3. Déconnecter les fils secondaires du ballast de la douille en insérant un petit tournevis dans l'arrière de la douille afin de libérer le fil électrique, ou déconnecter les connecteurs à torsader.
4. Retirer les vis de montage et retirer le ballast de l'assemblage de la lampe.
5. Remplacer le ballast par un modèle identique, fixer le ballast à l'assemblage de la lampe, insérer les fils secondaires du ballast en les poussant dans l'arrière de la douille, ou à l'aide des connecteurs à torsader, et effectuer correctement les raccords au câble d'alimentation.
6. Refixer la douille à l'aide des languettes (le cas échéant).

C. Ballasts Circulaires

1. Retirer la connexion 120v entre le ballast et le câble d'alimentation domestique.
2. Déconnecter les fils secondaires du ballast de la lampe en débranchant la prise.
3. Retirer les vis de montage et retirer le ballast de l'assemblage de la lampe.
4. Remplacer le ballast par un modèle identique et de même marque, fixer le ballast à l'assemblage de la lampe, effectuer correctement les raccords au câble d'alimentation et monter la douille aux lampes

D. Lampe à Ballast Intégré

1. Dévisser l'assemblage de la lampe à ballast intégré (du ballast) et retirer de la base. S'assurer de ne pas retirer en dévissant de la lampe au verre à spirale.
2. Monter le ballast neuf en verrouillant en place.

